Parkland Heritage©

ASSEMBLY AND OPERATING INSTRUCTIONS

Produced Exclusively by D. C. America

(Fits Model GOPDS86297 11. 5' x11. 5' HEXAGON GAZEBO)



CORPORATE OFFICE:

P.O.BOX 660999 Arcadia, CA91006

1-800-238-LAWN(5296)

Monday thru Friday, 8:30 AM to 4:30 PM, PST

Parkland Heritage©

is a trademark of D.C.America. All rights reserved.

Read Manual

Your Gazebo requires assembly prior to use. It is important that you read the entire manual and become familiar with the unit BEFORE you set up the Gazebo.

Safety Warning and Precautions

WARNING: When using product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

Read all instructions before assembling and using this product.

1. Select ideal location. Set out all parts on a clear and level surface prior to assembly. Ideally, the Gazebo should be set up in the desired location to avoid moving it after assembly.

2. Use caution. During the assembly process, especially when lifting heavy or large parts, pay attention to safety. Only those assembling the product should be allowed in the work area.

3. Tools and Assistance. Ladder and wrench are self-provided. Whenever possible, assistance is prefcrred.

4. Check for parts available. Before assembling your Gazebo, make sure that you have all parts described in the Parts List on page 3.

5. Check for damaged parts. Before assembling your Gazebo, check for damaged parts. Any part that appears damaged should be carefully checked to determine if it can operate properly and perform its intended function. Any part that is damaged should be properly repaired or replaced by a qualified technician.

6. Refer to assembly diagram. During assembly, it is helpful to refer to the assembly diagrams provided.

7. Keep children away. Children should be kept away from the work area. Do not allow children to handle any parts or tools. No one other than the assemblers shall be allowed in the work area.

8. Please keep this Assembly Instruction for future use.



A		4 PCS
B		1PC
C		1PC
D		1PC
E		5 PCS
F		6 PCS
G		1PC
H		5 PCS
I		1PC
J		1PC
K	M6 x 15mm	20 PCS
L	M6 x 30mm	6 PCS
M	M6 x 35mm	6 PCS
N	M6 x 45mm	12 PCS
P		12 PCS
O		1PC



①Attach the fence(E) to post(A/B/C) with bolt(K)
②Attach the lintel(D) to post(B/C) with bolt(N)



③Insert lintel(H) to connect post(A/B/C) with bolt(N)



④Connect all top tube(F) to center connector(G) using (L) nuts and bolts.



⑤Lay connected(F+G) top tube piece to the top of gazebo, attach end of tubes to posts(A/B/C) using(M) nuts and bolts
⑥Cover top of gazebo frame using fabric(I).
⑦Attach cap(J) to center connector(G), then pull the fabric(I) and secure to the end of (F) top tubes.
⑧Adjust the position of the gazebo, secure to ground by inserting stake(P) into the holes of the base plate.
Now your gazebo is ready for use!

How to prevent a sagging top,

1. Disconnect the tops & let hang down or take off the top in storms, snow etc…..
2. Make sure the Velcro is very tight & top is snug.
3. Apply a water proof spray to the top for longer lasting use.
4. Manufacture recommends removing canopy top during high winds and inclement weather.

Care and Maintenance of your Gazebo / Pavilion:

- With a natural tendency to rust steel furniture periodically should be touched up with paint and covered.
- Canopy top should be washed with a mild soap and water. Do not use abrasive materials or strong detergents.
- If scratched down to the bare metal, sand with a wire brush or fine grained sandpaper, apply to coats of rust inhibiting paint such as "Rust-Oleum" and follow with a matching top coat.